


## Connection Guide Avantis with GX4816 & DX168

# ALLEN & HEATH



Please note that items may not be sized to scale.

### Parts List

- One - Avantis w dPack
- One - GX4816
- One - DX168 expander box
- One - AH-M-DL-Dante64-A

### Notes

- Avantis is capable of mixing 64 inputs x 42 outputs.
- This scenario gives you 60 x 28 at FOH and 16 x 8 on the stage. You would need to select which inputs you would like to create your 64.
- Dante card is capable of 64 x 64 at 96kHz or 48kHz.
- GX4816 has a second expansion port that can be used to connect the 48kHz ME personal monitor mixers.

If you have any questions please contact your local rep.  
Find more drawings at [www.ProTechM.com/tools](http://www.ProTechM.com/tools)